



TURNDOWN EXHAUST EXTENSIONS

7606

PARTS INCLUDED

- 1 Chrome Turndown Extension — Left
- 1 Chrome Turndown Extension — Right
- 6 M-6 x 1.0 x 12mm Hex Head Flange Screws
- 1 Anti-Seize Package
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of Metric Combination Wrenches, Set of Metric Hex Wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 Put the bike on the center stand and remove the stock exhaust tips. The three fasteners securing each tip are located on the bottom and inboard sides of the tips.

STEP 3 Slip the Küryakyn Turndown Extensions onto their respective mufflers. Apply a dab of the included anti-seize to each M6 x 1.0 x 12mm Hex Flange Screws and loosely install the extensions using these and the existing mounting holes.

STEP 4 Align the tips. There is usually enough play in each extension's mounting holes to rotate them into alignment. If for some reason the tips do not afford enough adjustment, loosen the clamp that secures the muffler to the head pipe and rotate the entire muffler body. Once properly aligned, tighten all fasteners securely and wipe off the extensions and mufflers.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.

Ride On!