

## INSTALLATION INSTRUCTIONS

### TOE REST CRUISE PEG, SATIN BLACK

7633

#### THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

**WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

**NOTICE** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

#### ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

2	Toe Rest Cruise Peg Assemblies	1	Hardware Kit containing:
2	Toe Kick Half	2	M6 X 1.0 X 16MM Socket Head Cap Screws
		2	M6 X 1.0 X 20MM Socket Head Cap Screws

#### YOU WILL ALSO NEED:

Set of hex wrenches, set of metric hex wrenches

**NOTICE** THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn **IGN OFF**. If possible, secure the motorcycle in a wheel chock. Allow the engine and exhaust system to cool.
- STEP 2** Determine the mounting location for both of the Toe Rest Cruise Pegs before beginning.
- STEP 3** Refer to PIC 1. Position the Toe Rest Cruise Peg and Clamp half together around the bar as shown.
- STEP 4** Refer to PIC 1. Secure the Clamp half to the Toe Rest with one of the included M6 X 1.0 X 16MM Screws and one M6 X 1.0 X 20MM Screw; leave the Screws snug for now to allow for adjustment.
- STEP 5** Position the Toe Peg as desired; tighten the M6 Screws to secure the assembly to the bar.
- STEP 6** Ensure that the position of the Toe Rest does not interfere with the proper operation of the motorcycle **BEFORE** riding.



## INSTALLATION INSTRUCTIONS

### TOE REST CRUISE PEG, SATIN BLACK

7633

-CONTINUED-

**STEP 7** Repeat **STEPS 2 through 6** for the other side.



**⚠ WARNING**

BEFORE RIDING, ENSURE THAT THE INSTALLATION OF THIS PRODUCT DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE.

**NOTICE**

IT IS THE END USER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST OR DAMAGED DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.