



## REAR FENDER TIP 07-UP FATBOY

7787

### PARTS INCLUDED

- 1 Rear Fender Tip
- 1 Alcohol pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**


**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

**STEP 2** Remove any grease or debris from the rear fender installation area with soapy water and a clean rag; rinse and allow the area to dry completely. Clean the area with the included alcohol cleaning pad to remove any residue; allow the area to dry completely.

**ATTENTION!** Thoroughly clean the area of grease, oil, dirt, or other debris to ensure proper adhesion. Kuryakyn WILL NOT warranty any parts lost due to improper installation.

**ATTENTION!** The adhesive may not correctly bond if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F. Rub the backing on the adhesive strip to activate the adhesive before applying.

**STEP 3** Test fit the fender tip to the rear fender. There is a lip on the trim that will fit to the bottom of the fender PIC 1. Rub the backing on the adhesive strip to activate the adhesive before applying. Remove the adhesive backing. Press the trim into place for 1 minute to ensure proper adhesion. Full bond strength will occur within 24 hours. PIC 2



*Ride On!*