



**REAR FENDER ACCENTS 7797**

**FITS: '06-UP FLHX STREET GLIDES**

**PARTS INCLUDED**

- 4 Fender Accents
- 1 Alcohol Pad
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**PROCEDURE**

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

**ATTENTION!** The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

**STEP 2** Clean the lower rear fender light area (PIC 1). If the area is extremely dirty, clean with a mild soap and warm water, rinse with clean water and allow the area to dry completely.

**ATTENTION!** Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Kuryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

**STEP 3** Test fit the accents to the lower fender. Use temporary markings with masking tape to aid in final installation. The accents will fit between the lights and above/below (PIC 2).

**STEP 4** Clean the area with the supplied alcohol pad and allow to dry completely.



**-cont.-**

**STEP 5** Rub the adhesive backing on the accents to activate the adhesive. Remove the tape backing and apply the accents to the lower fender one at a time.

**STEP 6** Press and hold the accents in place for one minute. Full bonding strength will occur in 24 hours.

*Ride On!*

**Kuryakyn®**

PIC. 2



**PAGE**  
**2**

**REAR FENDER ACCENTS**

**INSTALLATION**