



STARTER COVER

7846

FOR '99-'06 TOURING

FITS: '99-'06 DRESSER, ROAD KING, ROAD GLIDE, STREET GLIDE

PARTS INCLUDED

- 1 Starter Cover
- 1 Hardware Kit Including:
 - 2 M4 x .7 x 40mm Button Socket Cap Screws (BSCS)
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of hex wrenches, combination wrenches or socket set and ratchet.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 Remove the top two solenoid cover screws shown in [PIC.1](#).

-cont.-



NOTE There may be excess paint on the head of the bolts that may need to be scraped off in order to remove them.

STEP 3 Test fit the cover and ensure that the wires will be located in the notches in the cover. It may be necessary to loosen the nut securing the wires and adjust them and retighten them.

CAUTION! Avoid potential electrical shock! Disconnect the battery before starting this procedure.

STEP 4 Install the cover making sure that the wires will not be pinched; line up the holes in the cover with the holes in the solenoid cover and secure using the two M4 x .7 x 40mm screws, do not over tighten.

Ride On!

Kuryakyn

PAGE

2

STARTER COVER INSTALLATION