



ISO PASSENGER BOARDS

7906

PARTS INCLUDED

- 1 Passenger Footboard Assembly — Left
- 1 Passenger Footboard Assembly — Right
- 1 Anti-Seize Packet
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

NOTICE

IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.

TOOLS SUGGESTED

Set of Hex Wrenches, Soapy Water Solution, Grease, Needle Nose Pliers

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let cool.

WARNING

YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2

With the footboards folded up, wet the small rubber nubs that protrude through the footboard bodies with soapy water solution. Fold the boards down and pull the rubber pads free from the stock footboard bodies.

-cont.-

STEP 3 Remove the pivot pins from the board assembly. Once you have pushed them as far as possible with your fingers, you may grasp them with a needle nose pliers and remove them the rest of the way.

STEP 4 Remove the footboard from the mounting bracket.

NOTE: There is a small detent ball that will most likely fall from the footboard mounting bracket. Be prepared to catch it or at least watch where it rolls.

STEP 5 See PIC 1. To help keep the detent ball in place during the installation of the new footboard, place a dab of grease on the hole in the mount that holds the detent ball and spring. Place the detent ball into position as shown in PIC 2.

STEP 6 Using your hex wrenches, remove the hinge pins from the ISO Boards. Apply anti-seize to the threads of the hinge pins.

NOTICE Use the supplied anti-seize for any chrome-to-chrome fasteners; this will prevent galling and make future removal of fasteners easier.

STEP 7 Position the board on the mount (tapered end of the board goes forward) and apply very slight downward pressure to compress the detent spring. Insert the hinge pins into their respective holes and tighten securely.

STEP 8 Periodically check these hinge pins for tightness.

NOTICE It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.



Ride On!

-cont.-

PRODUCT NAME HERE

INSTALLATION

PAGE

2