



**CYLINDER BASE COVER**

**8143**

**FITS: '99-'06 ELECTRA GLIDES, ROAD GLIDES, STREET GLIDES AND ROAD KINGS; '00-'06 SOFTAILS; '99-'05 DYNAS WITH FORWARD CONTROLS**

**CAUTION!** Do not use this cover on modified engines with 4-inch or larger cylinder bore.

**PARTS INCLUDED**

- 1 Twin Cam Cylinder Base Cover
- 1 5/16-18 x 3-1/4" Socket Head Cap Screw (SHCS)
- 1 5/16" Hot Spot
- 2 3/4" Dia. x 3/16" Thick Adhesive Foam Pad
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**TOOLS SUGGESTED**

Set of Hex Wrenches, Socket Set and Ratchet, Torque Wrench (Ft/lbs)

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**PROCEDURE**

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

**WARNING!** YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

**STEP 2** Disconnect the shift linkage from the splined shifter shaft and lay it on the primary.

**STEP 3** Remove the top center case bolt. This bolt is located on the left side of the engine.

**STEP 4** Place the cover in place and secure with the supplied 5/16-18 x 3-1/4" SHCS.

**STEP 5** Torque the fastener from Step 4 to 18 ft/lbs.

**STEP 6** Insert the chrome Hot Spot in to the head of the mounting fastener.

**STEP 7** Re-connect the shift linkage. Check for correct functionality before riding.

**ATTENTION!** It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

*Ride On!*

**Kuryakyn**<sup>®</sup>

**PAGE**

**2**

**CYLINDER BASE COVER**

**INSTALLATION**