



DELUXE INNER PRIMARY COVER

8291

PARTS INCLUDED

- 1 Chrome Inner Primary Cover
- 1 Hardware Kit Including:
 - 2 "L" Brackets
 - 1 "Z" Bracket
 - 4 #6-32 x 1/4" Slotted Pan Head Screw
 - 1 1/4"-20 x 1/2" Socket Head Cap Screws
 - 1 1/4" I.D. Split Lock Washer
 - 1 1/4" I.D. Flat Washer
 - 1 5/16"-18 x 1-3/4" Hex Head Cap Screw
 - 1 5/16" I.D. Flat Washer
 - 1 Anti-rattle Gasket — Foam
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of Hex Wrenches, Socket Set and Ratchet, Torque Wrench-ft/lbs and in/lbs, Blade Screwdriver

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

-cont.-

STEP 2 See PIC.1. Remove the four stock fasteners indicated.

STEP 3 Install the two "L" brackets as shown in PIC.2 using the supplied four #6-32 X 1/4" slotted pan head screws.

STEP 4 Install the "Z" bracket as shown in PIC.3 using the supplied 1/4"-20 X 1/2" socket head cap screw, 1/4" lock washer and 1/4" flat washer.

STEP 5 Place the cover in position on the inner primary case. Secure the front mounting point with the 5/16"-18 x 1-3/4" hex head cap screw provided. **Torque to 17 foot pounds.**

STEP 6 Secure the remaining three mounting points with the stock socket head cap screws removed in STEP 2. **Torque to 108 inch pounds.**

ATTENTION! It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Küryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

