

# CYLINDER BASE COVER

8392

FITS: ALL '07-UP ROAD KINGS, ROAD GLIDE, STREET GLIDE, ELECTRA GLIDE, AND ALL '06-UP DYNA MODELS.

#### PARTS INCLUDED

- 1 Cylinder Base Cover
- 1 Hot Spot
- 1 5/16"-18 x 3-1/4" Socket Head Cap Screw
- 1 5/16-18 x 4" Socket Head Cap Screw
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

## THANK YOU FOR CHOOSING KÜRYAKYN!

#### **PLEASE NOTE**

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Küryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE DURING INSTALLATION ENSURE THAT THE ENGINE HAS FULLY COOLED TO PREVENT INJURY.

### **TOOLS SUGGESTED**

Set of hex wrenches, set of combination wrenches, torque wrench with hex bits/sockets.

### **PROCEDURE**

**STEP 1** Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

- **STEP 2** Remove the nut and lock washer on the front of the shift linkage; disconnect the front end of the shift linkage from the shifter lever. Secure the shift linkage up and out of the way during the rest of the installation.
- **STEP 3** Remove the stock fastener on the left side of the crankcase as shown in PIC.1.
- **STEP 4** Position the Cylinder Base Cover in place and secure it with the included 5/16"-18 x 3-1/4" Socket Head Cap Screw. 96" and 103" engines use the 3-1/4" long screw. 110" engines require the 4" screw. Torque the fastener to 15-19 ft. lbs.
- **STEP 5** Push the Hot Spot into the head of the new fastener.
- **STEP 6** Reconnect the shift linkage and shift lever; tighten the nut.
- **STEP 7** Check for proper clearance before operating the motorcycle.

