



**STINGER VENTED TRAP DOOR 8498**

**FITS: ALL STANDARD HYPERCHARGER BODIES - LATE, EARLY AND EFI**

**PARTS INCLUDED**

- 1 Stinger Vented Trap Door — Chrome
- 1 Flat Filter Cage
- 1 Cup Filter Cage
- 1 Black Foam Air Filter
- 4 10–24 X 3/8" Socket Head Cap Screws
- 1 Installation Instruction

*Please read and understand entire instructions before starting installation.*

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**TOOLS SUGGESTED**

1/8" Hex Key wrench

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**PROCEDURE**

**STEP 1** Use a 1/8" hex key wrench; remove the four button head cap screws from the trap door on the hyper.

**STEP 2** Remove the trap door and the trap door gasket.

**STEP 3** Set the filter assembly in place with the cup section of the filter cage inside the Hypercharger. Hold the Stinger Vented Trap Door in place and line up the mounting holes in the Stinger, the filter and the Hypercharger. Secure the Stinger and filter to the Hypercharger using the supplied 10–24 X 3/8" Socket Head Cap Screws and tighten.

**FILTER CLEANING TIPS**

- Separate the two halves of the filter cage to remove the filter.
- Using a mild soap and warm water solution and let the filter soak for a short time. Rinse thoroughly and allow to air dry, then re-oil with foam filter oil. Do not use high-pressure water to wash the filter. Do not use compressed air to dry the filter. K&N Filter Care Kit, Küryakyn P/N 85 may also be used.

*Ride On!*