



FORK BRACE FOR WIDE GLIDE 8620

FITS: '80-UP UNSHROUDED WIDE GLIDE FRONT ENDS (FXWG, FXDWG, FXST, ETC.)

PART#	INCLUDED
608620	1 Fork Brace – Chrome
400820	1 3/16" Allen Wrench
400865	1 5/32" Allen Wrench
308620	1 Instruction Sheet

TOOLS SUGGESTED

Supplied 3/16" and 5/32" Allen Wrenches

PROCEDURE

STEP 1 Using the 3/16" Allen wrench included with the kit, remove the four screws that hold the two outside clamp halves to the fork brace.

STEP 2 Using the 5/32" Allen wrench included with the kit, loosen, but do not remove the four button head screws that secure the fork brace to the remaining halves.

USE CARE NOT TO SCRATCH THE FENDER WHILE PERFORMING THE FOLLOWING STEPS.

STEP 3 Position the fork brace, cross member up, between the fork sliders so the clamp halves will clamp on the area just below the fork slider dust covers.

STEP 4 Loosely install the outside clamp halves, tighten them just enough to hold them in place.

STEP 5 By moving the fork brace from side to side and by rotating the fork slider clamps, make sure all components are square and in alignment. Snugly tighten the screws that hold the fork brace to the inside clamp halves first, then snugly tighten the screws that hold the clamp halves together.

Ride On!

