



**REAR FENDER ACCENT**

**8640**

**FITS: ROAD GLIDE, ROAD KING CUSTOMS AND SCREAMIN' EAGLE DRESSERS OR ROAD KINGS**

**PARTS INCLUDED**

- 1 Rear Fender Accent
- 1 Alcohol Pad
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**TOOLS SUGGESTED**

Soapy water and a clean rag

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**PROCEDURE**

**STEP 1** Park the motorcycle on a hard, level surface; turn off the ignition.

**STEP 2** Remove any grease or debris from the rear fender with soapy water and a clean rag; allow the area to dry completely. See PIC.1.

**ATTENTION!** Thoroughly clean the area of grease, oil, dirt, or other debris to ensure proper adhesion. Kuryakyn WILL NOT warranty any parts lost due to improper installation.

**ATTENTION!** The adhesive may not correctly bond if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

-cont.-



**STEP 3** Clean the area (shown in [PIC.1](#)) with the included alcohol cleaning pad; allow the area to dry completely.

**STEP 4** Rub the backing on the adhesive strip to activate the adhesive before applying.

**STEP 5** Remove the adhesive backing.

**STEP 6** Hold in place for one (1) minute to ensure proper adhesion. Full bond strength will occur within 24 hours.

**STEP 7** Ensure proper clearance and operation before riding the motorcycle.

*Ride On!*

**Kuryakyn**

**PIC.2**



**PAGE**

**2**

**REAR FENDER ACCENT** **INSTALLATION**