



FRONT FENDER ACCENT

8642

FITS: STREET GLIDE, ROAD GLIDE, ROAD KING CUSTOMS AND SCREAMIN' EAGLE DRESSERS OR ROAD KINGS (EX. '07 FLHRSE)

PARTS INCLUDED

- 1 Front Fender Accent
- 1 Alcohol Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Soapy water and a clean rag

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Park the motorcycle on a hard, level surface; turn off the ignition.

STEP 2 Remove any grease or debris from the front fender with soapy water and a clean rag; allow the area to dry completely. See [PIC.1](#).

ATTENTION! Thoroughly clean the area of grease, oil, dirt, or other debris to ensure proper adhesion. Kuryakyn **WILL NOT** warranty any parts lost due to improper installation.

ATTENTION! The adhesive may not correctly bond if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

-cont.-



STEP 3 Clean the area (shown in [PIC.1](#)) with the included alcohol cleaning pad; allow the area to dry completely.

STEP 4 Rub the backing on the adhesive strip to activate the adhesive before applying.

STEP 5 Remove the adhesive backing.

STEP 6 Hold in place for one (1) minute to ensure proper adhesion. Full bond strength will occur within 24 hours. See [PIC.2](#).

STEP 7 Ensure proper clearance and operation before riding the motorcycle.

Ride On!

Kuryakyn

PIC.2



PAGE

2

REAR SADDLEBAG ACCENTS

INSTALLATION