

INSTALLATION INSTRUCTIONS

FILLER PAD FOR TOUR-PAK® RELOCATOR

8742

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Tour-Pak Relocator Pad

YOU WILL ALSO NEED:

Socket wrench set

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

STEP 2 Clean the area between the back of the seat and the Tour Pak with soapy water and a clean rag; rinse and allow the area to dry completely.

NOTICE THOROUGHLY CLEAN THE AREA OF GREASE, OIL, DIRT, OR OTHER DEBRIS TO ENSURE PROPER ADHESION. KURYAKYN WILL NOT WARRANTY ANY PARTS LOST DUE TO IMPROPER INSTALLATION.

NOTICE THE ADHESIVE MAY NOT CORRECTLY BOND IF APPLIED AT TEMPERATURES LESS THAN 50°F. DO NOT ATTEMPT THIS INSTALLATION IN TEMPERATURES LESS THAN 50°F. RUB THE BACKING ON THE ADHESIVE STRIP TO ACTIVATE THE ADHESIVE BEFORE APPLYING.

STEP 3 Remove existing hardware from the tour pak case, located under the passenger's back pad. Set hardware aside until step 4.

STEP 4 Locate the Tour-Pak Relocator Pad.

Refer to PIC 2. Attach the pad to the tour pak using the hardware removed in step 3.

Refer to PIC 3. Secure the hook and loop straps around wiring under the passenger seat.

NOTE: This Pad is intended to fill the open area between the rear of the passenger seat and the Tour-Pak when using Kuryakyn's Tour-Pak relocator, P/N 8956 or 8731. Depending on the location of the Tour-Pak, it may sit flat or be angled up.

