

INSTALLATION INSTRUCTIONS

CLEAR TRAP DOOR FOR STANDARD HYPERCHARGER, CHROME

8746

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Trim Ring
- 1 Clear Trap Door
- 1 Gasket

YOU WILL ALSO NEED:

1/8" Hex Key Wrench

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

INSTALLATION OF THE CLEAR TRAP DOOR IS SHOWN DONE ON A HYPERCHARGER OFF THE BIKE.

INSTALLATION FOR THE TRAP DOOR IS THE SAME ON AND OFF THE BIKE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Use a 1/8" hex key wrench; remove the four button head cap screws from the trap door on the hypercharger. Set screws aside until step 3. Remove the existing trap door and trap door gasket.

STEP 3 Locate the Gasket, Clear Trap Door, and Trim Ring provided. Align the holes of the gasket with the holes of the hypercharger. Remove the clear flim from the clear trap door. Align and place the clear trap door ontop of the gasket, followed by and the trim ring.



INSTALLATION INSTRUCTIONS

CLEAR TRAP DOOR FOR STANDARD HYPERCHARGER, CHROME

8746

-CONTINUED-

- STEP 4** Using the screws that were removed in step 2, secure the trap door to the hypercharger.



FILTER CLEANING TIPS

Separate the two halves of the filter cage to remove the filter.

Using a mild soap and warm water solution and let the filter soak for a short time. Rinse thoroughly and allow to air dry, then re-oil with foam filter oil. Do not use high-pressure water to wash the filter. Do not use compressed air to dry the filter. K&N Filter Care Kit, Kuryakyn P/N 85, may also be used.

NOTICE

IT IS THE END USER'S RESPONSIBILITY TO ENSURE THAT ALL FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST OR DAMAGED DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.