



SPLINED ADAPTER FOR HONDA 8815

FITS THE FRONT FOOT PEG MOUNTS ON '00-UP 750 SPIRIT, '04-UP 750 AERO, '96-'04 750 MAGNA, '96-UP 600 VLX, '96-UP 600 VLX DELUXE MODELS.

PART #	INCLUDED
408815	2 Splined Adapters
308815	1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

TOOLS SUGGESTED

Allen wrenches and pliers.

PROCEDURE

STEP 1 Remove the stock footpeg. Save the stock fasteners.

STEP 2 Install the splined adapter and secure with the stock fasteners. Install your new Kuryakyn footpeg or floorboard. Repeat for the opposite side.

Ride On!