



**ROUND SHIFT PEG COVER**

**8852**

**PARTS INCLUDED**

- 1 VTX Shift Peg Assembly
- 1 Hardware Kit for VTX including the following part:
  - 1 #10-24 x 3/8" Steel Set Screw with Blue Thread Lock Patch
  - 1 Tube Adhesive
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

**TOOLS SUGGESTED**

Set of Hex Wrenches, Emery Cloth or Sand Paper

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let cool.

**WARNING!** YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

**NOTE:** The glue provided in this kit dries very quickly with the lack of oxygen, PLEASE follow STEP 5 carefully.

-cont.-

**STEP 2** Remove the OEM rubber on shifter shaft. If your shifter shaft is smooth (where glue is being applied in PIC.2) ruff it up with emery cloth or sand paper so that the glue will adhere better.

**ATTENTION!** Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Küryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

**ATTENTION!** The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

**STEP 3** Peel rubber out and back on shift peg cover as shown in PIC.1.

**STEP 4** Apply glue to the inside of the new shift cover and also on the very outside edge of the shifter arm (as shown in PIC.2) where the new cover will be installed.

**STEP 5** Slide shift cover fully onto shifter arm and rotate cover so that the set screw is at the bottom. Hold shift cover in place until glue has set. Apply glue under the rubber pads that you peeled out and back. Push rubber pads back into place.

**STEP 6** Secure the cover using a hex wrench.

**ATTENTION!** It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.

PIC 1



PIC 2

