

INSTALLATION INSTRUCTIONS

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

- ⚠ WARNING

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.
- ⚠ CAUTION

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.
- NOTICE

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 2

Splined Adapters
- 1

Hardware Kit, containing:

2

“D” Spring Washers

2

External Snap Rings

YOU WILL ALSO NEED:

Small screwdriver or pick tool, external snap-ring pliers

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
- STEP 2

Use a small screwdriver or pick tool to remove the OEM spiral spring retainer from the pin. BE PATIENT! Lift the leading edge of the retainer out of the groove in the pin. Slide the retainer off the pin; it will “unwind” as it is removed. Discard the retainers, they will not be reused.
- STEP 3

Remove the pins from the mounts; remove the existing pegs; save the pins.
- STEP 4

Refer to PIC 2. Loosely install the footrest, sold separately, on the Adapter. The Adapters are NOT side specific.

Note: The footrest does not need to be fully installed right now, but by installing it to the adapter it will help create ease of installation for the adapter itself.
- STEP 5

Refer to PIC 2 and 3. Slide the footrest assembly into the mount; align the holes and secure with the existing pin. If the assembly has a loose fit, install the included “D” washer in between the mount and Adapter.



INSTALLATION INSTRUCTIONS

SPLINED PEG ADAPTER FOR VICTORY® & INDIAN®, SATIN BLACK

8893

-CONTINUED-

STEP 6 Refer to PIC 4. Secure the pin with the included Snap Ring; ensure that the Ring fully seats in the groove; it should spin freely when installed correctly.

STEP 7 Repeat STEPS 4 through 6 for the other side.

STEP 8 Adjust and finish installation for the Kuryakyn footpegs or floorboards that require a Splined adapter as per the instructions with the footpegs or floorboards.

⚠ WARNING FOOTRESTS MUST BE INSTALLED SO THEY WILL FOLD UPWARD AND REARWARD IF HIT BY ANY OBJECT. FAILURE TO ADJUST THE FOOTRESTS TO OPERATE IN THIS MANNER COULD RESULT IN SERIOUS INJURY OR DEATH.

NOTICE IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.



PIC 4



FINAL