

INSTALLATION INSTRUCTIONS

SPLINED PASSENGER PEG ADAPTER FOR SOFTAIL, GLOSS BLACK

8924

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 2 Splined Peg Adapter

YOU WILL ALSO NEED:

Snap ring pliers

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

WARNING YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

WARNING A FACTORY SERVICE MANUAL WILL BE HELPFUL IN PERFORMING THIS INSTALLATION. DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN. IMPROPER INSTALLATION COULD RESULT IN SERIOUS INJURY OR DEATH.

STEP 2 Carefully remove the stock peg from the clevis. Be careful not to lose the detent ball or spring when removing the peg. Set all hardware aside, it will be reused.

STEP 3 Refer to PIC 4. Locate a provided splined adapter, as well as the spring, detent ball and adapter plate that were removed in step 2.

STEP 4 Refer to PIC 5. Place the spring into the bottom front closed off hole of the adapter and place the detent ball on top of the spring.

STEP 5 Refer to PIC 5 and 6. Align the plate with the adapter. Carefully slide the plate over the ball until it snaps into place on the farthest back hole of the plate.

PIC 1



PIC 2



PIC 3



PIC 4



PIC 5

PIC 6



INSTALLATION INSTRUCTIONS

SPLINED PASSENGER PEG ADAPTER FOR SOFTAIL, GLOSS BLACK

8924

-CONTINUED-

STEP 6 Refer to PIC 7. Align and place the adapter with the clevis, be sure the mounting holes are aligned properly.

STEP 7 Refer to PIC 8 and 9. Secure the splined adapter in the clevis using the OEM hardware that was remove in Step 2. Check that the splined adapter is installed correctly and the splined adapter is able to fold upward.

STEP 8 Repeat Step 2 through Step 7 for the other side.


STEP 9 Finish the installation by following the procedures included with the footrests (sold separately).

⚠ WARNING FOOTRESTS MUST BE INSTALLED SO THEY WILL FOLD UPWARD AND REARWARD IF HIT BY ANY OBJECT. FAILURE TO ADJUST THE FOOTRESTS TO OPERATE IN THIS MANNER COULD RESULT IN SERIOUS INJURY OR DEATH.

⚠ CAUTION ENSURE THAT THE INSTALLATION OF THIS PRODUCT DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE BEFORE RIDING.

⚠ WARNING IMPROPER INSTALLATION OR USE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

NOTICE IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.



PIC 7



PIC 8



PIC 9