

INSTALLATION INSTRUCTIONS

SPLINED DRIVER PEG ADAPTER FOR SOFTAIL, CHROME

8945

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 2 Splined Adapters

YOU WILL ALSO NEED:

Snap ring pliers

PICTURES SHOWN ARE OF THE BLACK PARTS. INSTALLATION OF THE CHROME PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

PIC 1



STEP 2 Refer to PIC 2. Pay attention to how the spring is set in the existing peg. Carefully remove the retaining clip, pivot pin, stock peg and spring from the clevis. Set the spring, pivot pin, and retaining clip aside, they will be reused.



PIC 3

STEP 3 Refer to PIC 3. Locate one (1) provided adapter and the OEM spring that was removed in Step 2. Set the spring into the new adapter the same way it was positioned in the stock peg. Align and place the adapter and spring into the clevis.



PIC 4

STEP 4 Refer to PIC 4. Locate the pivot pin and retaining clip that were removed in Step 2. Secure the splined adapter in the clevis using the OEM hardware. Check that the splined adapter is installed correctly and is able to fold upward.



INSTALLATION INSTRUCTIONS

SPLINED DRIVER PEG ADAPTER FOR SOFTAIL, CHROME

8945

-CONTINUED-

STEP 5 Refer to PIC 5. Install the Kuryakyn footpegs or floorboards that require a splined adapter as per the instructions with the footpegs or floorboards.

STEP 6 Repeat Steps 2 through 5 for the opposite side.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

