



CHROME REAR MASTER CYLINDER COVERS 9128

FITS ALL '99-UP TOURING MODELS (DRESSER, ROAD KING, ROAD GLIDE, STREET GLIDE, ETC.) AND ALL '00-UP SOFTAIL MODELS.

PARTS INCLUDED

- 1 Chrome Master Cylinder Cover with Sight Lens
- 1 Hardware Kit for Master Cylinder Cover Including:
 - 2 Stand-off Stud
 - 2 8-32 X 5/16" Button Head Cap Screw
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

TOOLS SUGGESTED

Phillips Screw Driver and a 5/16" Combination Wrench, Allen Wrenches

CAUTION

DOT 5 brake fluid is silicone based and normally not harmful to paint, it is a good idea to clean up any spills immediately just in case another type of brake fluid was used in a previous service.

PROCEDURE

STEP 1 Remove the two Phillips screws that fasten the reservoir top cover in place. (This is a good time to check your brake fluid level.)

STEP 2 Replace the stock Phillips screws with the stand-off studs included with this kit. Tighten securely but do not over tighten.

STEP 3 Set the cover in place over the master cylinder reservoir with the cut out along the bottom edge towards the inside.

STEP 4 Secure the cover in place using the included 8-32 X 5/16" button head cap screws.

Ride On!

