

## INSTALLATION INSTRUCTIONS

### THROTTLE BODY SUPPORT BRACKET, SATIN BLACK

9379

#### THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

**WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

**NOTICE** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

#### ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Throttle Body Support Bracket

#### YOU WILL ALSO NEED:

Hex Key Set, Hex Bit Socket Set, in-lbs (Nm) torque wrench, Blue Loctite

**NOTICE** THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

**PIC 1**



**STEP 2** Refer to PIC 2. Remove existing air cleaner. Unfasten the throttle body wire harness from the support bracket. Remove the existing breather bolts, support bracket mounting hardware and support bracket. Set mounting hardware aside, it will be reused.

**PIC 2**



*Note: Refer to your motorcycle's service manual for assistance.*

**STEP 3** Refer to PIC 3. Locate provided Throttle Body Support Bracket. Align the oblong holes of the support bracket with the mounting holes on top of the throttle body.

*Note: The small circle hole should be positioned on the right (front-facing) side.*

**STEP 4** Refer to PIC 4. Locate the OEM support bracket mounting hardware that was removed in Step 2. Apply a small amount of Blue Loctite to each bolt. Fasten the new support bracket to the top of the throttle body. Fully tighten hardware.

**PIC 3**



**PIC 4**



**TORQUE VALUE FOR MOUNTING SCREWS:**  
66-84 IN-LBS (7.5-9.5 NM)

**STEP 5** Fasten the throttle body wire harness to the small hole of the support bracket.

## INSTALLATION INSTRUCTIONS

### THROTTLE BODY SUPPORT BRACKET, SATIN BLACK

9379

-CONTINUED-

**STEP 6** For completion of air cleaner installment, refer to the installations instructions provided with the air cleaner (sold separately).

#### NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

