

INSTALLATION INSTRUCTIONS

PASSENGER BOARD BLOCK OFF PLATES FOR TOURING & TRIKE, GLOSS BLACK

9397

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 2 Peg Mount Block Off Plates
- 2 3/8-16 X 1/2" Button Head Cap Screws

YOU WILL ALSO NEED:

Set of hex wrenches, set of hex bit sockets, ft-lbs (Nm) torque wrench

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Refer to PIC 2. Remove existing passenger footpeg or floorboard and mounting hardware. Set them all aside, they will NOT be reused.

STEP 3 Refer to PIC 3 and 4. Locate one (1) provided Peg Mount Block Off Plate and one (1) Button Head Cap Screw. Align the top hole of the block off plate with the top mounting hole of the peg mount. Secure the plate to the mount by inserting and tightening the screw. Fully tighten hardware.

TORQUE VALUE FOR FOOTBOARD/FOOTREST UPPER FASTENER:
36-42 FT-LBS (48.8-56.9 NM)

STEP 4 Repeat Steps 2 through 3 on the opposite side.

NOTICE IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.



PIC 1



PIC 2



PIC 3



PIC 4



FINAL