



INSTALLATION INSTRUCTIONS

EXTENDED BRAKE PEDAL, '14-UP TOURING & TRIKE WITHOUT LOWERS, CHROME

9670

-CONTINUED-

- STEP 9** Clean and re-grease the pivot shaft.
- STEP 10** Slide the Extended Brake Pedal onto the shaft; secure it with the existing pivot pin, washer, and included Cotter Pin; bend the ends of the Cotter Pin.
- STEP 11** Secure the Pedal to the pivot shaft with the existing nut and washer; torque to 15-20 FT LBS (20.3-27.1 Nm).
- STEP 12** Secure the master cylinder to the motorcycle with the existing screws; torque to 10.5-12.5 FT LBS (14.2-17 Nm).
- STEP 13** Reinstall the floorboard and main fuse.

NOTICE

IT IS THE END USER'S RESPONSIBILITY TO ENSURE THAT ALL FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST OR DAMAGED DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.
