

## INSTALLATION INSTRUCTIONS

### CUSTOM TIE-DOWN BRACKETS, INDIAN® CHIEF

968

#### THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

**WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

**NOTICE** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

#### ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Right Tie-Down
- 1 Left Tie-Down

#### YOU WILL ALSO NEED:

Hex Wrench Set

**NOTICE** THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
- STEP 2** If applicable, remove windshield. Refer to motorcycle's service manual for assistance.
- STEP 3** Refer to PIC 1. Starting on the right side front fork, remove existing hardware from the outer edge of the front fork leg. Set hardware aside, it will be reused.

*Note: Process will vary between models, as some models may have a lighting system connected at these points. Refer to motorcycle's service manual for additional assistance.*

- STEP 4** Refer to PIC 2. Locate Right Tie-Down. Align the top hole of the Tie-Down with the top hole of the fork leg. Insert one of the screws that was removed from Step 3. Lightly tighten hardware.

*Note: If model has light system positioned over these holes, the Tie-Down bracket will be placed in between the fork leg and light system.*



## INSTALLATION INSTRUCTIONS

### CUSTOM TIE-DOWN BRACKETS, INDIAN® CHIEF

968

-CONTINUED-

- STEP 5** Refer to PIC 3 and 4. Align the bottom hole of the Tie-Down with the bottom hole of the fork leg. Insert the other screw into the aligned holes and tighten. Fully tighten both screws. Refer to service manual for torque specification.

*Note: If model has light system positioned over these holes, the Tie-Down bracket will be placed in between the fork leg and light system.*

- STEP 6** Repeat steps 3 through 5 for the left side.

- STEP 7** If applicable, reinstall the windshield.

#### NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

