



CATCH TANK FOR BLUE GRASS BREATHER 9931

FITS ALL MODELS USING THE BLUEGRASS BREATHER KIT, P/N 9930 OR 9932.

PART #	INCLUDED
609931	1 Catch Tank Assembly, including: 1 LIL Tank, Chrome 1 LIL Tank Inlet Rib, Chrome 1 Rubber Gasket 1 Vent Pipe 1 Oil-Safe Sponge
909931	1 Hardware Kit, including: 1 0.50 ID x 36" Hose 1 SST Universal Strap 1 5/16 – 18 x 1" SHCS Stainless Fastener 1 5/16 – 18 x 3/4" SHCS Stainless Fastener 2 5/16 – 18 High Crown Acorn Nut 2 5/16" Split Lock Washer 2 5/16" Flat Washer 2 3/4" Wire Clamp 4 6" Black Cable Tie
309931	1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Küryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

TOOLS SUGGESTED

Allen wrenches

NOTE: The universal catch tank can be mounted in a variety of ways. This procedure outlines two potential ways to mount the catch tank; always orient the catch tank upright with the vent slots at the top.

IMPORTANT GUIDELINES

- Always orient the catch tank upright with the vent slots on top.
- Be careful not to lose the o-ring sealing the tank to the cap.
- When installing, tighten the tank to the cap securely using an Allen wrench in the hex cutout in the bottom of the tank.
- Check and empty the catch tank regularly to avoid potential overflow. Regularly inspect the vents for weeping oil. If you find weeping oil, clean the sponge. Unscrew the tank from the cap using an Allen wrench in the bottom of the tank. Be careful not to lose the o-ring that seals the tank to the top cap. Squeeze the excess oil from the sponge; you may wash it with soap and warm water if it is dirty. Be sure to rinse the sponge thoroughly and squeeze out any excess water. Reinstall the tank to the cap in the reverse order.

-cont.-

INSTALLATION SUGGESTIONS

WARNING! Never mount the catch tank where an overflow could deposit oil directly onto a tire. This could cause loss of control while operating the motorcycle.

- The catch tank can be mounted with either the supplied universal strap or a P-Clamp (sold separately). PIC.1 shows the catch tank mounted to the horn bracket using the supplied universal strap.
- PIC.2 shows the tank mounted to the frame using a Kuryakyn P-Clamp (sold separately). P-Clamps are available in a variety of sizes to cover many applications.

Ride On!

PIC.1



UNIVERSAL STRAP

PIC.2



P-CLAMP