

Instructions for Linbar[®] and Multibar[®] Part # 105-1, 1305, 1405

Fits Dyna Models from 1991-present.
Will only fit with mid controls.

**LINDBY
CUSTOM, INC.**

1. Install top center mount of the highway bar to the center mount of the frame using 5/16" x 18 Bolt and Nylon Lock Nut
2. Install Left and Right lower mount of the highway bar to the lower hole on the side of the frame using 3/8" x 16 bolts and washers
3. Tighten all bolts
4. Hardware included:
 - 1 Hex bolt 5/16 x 18 x 1
 - 2 Allen bolts 3/8 x 16 x 1
 - 1 Nylon Lock nut 5/16
 - 2 Sae flat washers 5/16
 - 2 Sae flat washers 3/8

*Bar width: 35"



Front Linbar patent D361311
Front Multibar patent D548142

Rely only on high-grade motorcycle frame & body offered on our virtual shelves.