

Instructions for Linbar®

Part # 109-1/09

Fits Road Glide 1998-present

**LINDBY
CUSTOM, INC.**

1. Loosen and remove left and right side fairing supports.
2. Remove OEM engine guard.
3. Install top mount so the top bracket fits inside the frame (the nut is adjustable in the bracket). After you mount the top bolt through the frame into the adjustable nut, be sure you can move the bar up and down for easier installation of the two lower mounting bolts.
4. Install the 5/16" allen bolt through the frame and then into the highway bar.
5. Install the 2 lower mounts using the bolts you took out in step one or use the two 3/8" x 16 x 1 1/4" bolts supplied in the hardware kit.
6. Install left and right faring supports. On 2010 and newer models only, mount the left side bracket on the right and the right side bracket on the left.
7. Tighten all bolts to factory specifications.
8. Hardware Included:
 - 1 Allen Bolt 5/16 x 18 x 1
 - 2 Hex Bolts 3/8 x 16 x 1 1/4
 - 2 Nylon Lock Nut 3/8 x 16
 - 1 Sae Flat Washer 5/16
 - 4 Sae Flat Washers 3/8

