

Instructions for Linbar[®], Multibar[®] and Unibar[®] Part # 111-1, 1311, 1411


Fits 2000-present Softail models.

For 1986-1999, use bracket kit part #111-5
with Linbar or Multibar.

**LINDBY
CUSTOM, INC.**

1. Install the top mount of the highway bar using the 5/16" x 1" bolt. Install the long spacer between the frame and the Highway bar. The curved side should be facing the bar. Do not tighten the bolts yet.
2. Install the 2 lower mounts of the highway bar to the mounting point on the l & r forward controls using the 3/8" x 1 1/4" bolts and nylon locknuts.
3. Tighten all bolts to manufacturer's specifications.
*Note: it may be necessary to loosen up the three torque bolts on the L/R side, then secure the forward controls/ floor board brackets to the frame to get the lower mounting point to line up.
* Breakout Model: The Weld Nut on the Horn Bracket will need to get drilled out.
4. Hardware included:
 - 1 Hex bolt 5/16 x 8 x 1
 - 2 Hex bolts 3/8 x 16 x 1 1/4
 - 2 Nylon lock washers 3/8 x 16
 - 2 Sae flat washers 5/16
 - 4 Sae flat washer 3/8
 - 1 3" Curved Spacer

*Bar width: 34 3/4



Front Linbar patent D361311
Front Multibar patent D548142

Rely only on high-grade motorcycle frame & body offered on our virtual shelves.