

Instructions for Linbar[®], Multibar[®] and Unibar[®] Part # 114-1, 1314 and 1414

Fits Harley Davidson Dyna Switchback, 2010-present

LINDBY
CUSTOM, INC.

1. Loosen the bolts that secure the left and right side brackets of the floorboards to the frame.
2. Install the spacer with the 2 holes between the frame and the rear floorboard bracket and install the bracket with the 3 holes between the front floorboard bracket and the frame. See drawing below for the direction of the bracket.
3. Tighten the bolts for the left and right side floorboards brackets.
4. Install the top mount of the highway bar to the mounting hole located at the base of the two down tubes of the frame below the lower triple tree.
5. Install the lower mounts of the highway bar to the front brackets installed in section 2 and tighten the mounting bolts for the highway bar.
6. Hardware included:
 - Hex Bolts 3/8 x 16 x 1
 - 2 Nylon Lock Nuts 3/8 x 16
 - 6 Sae Flat Washers 3/8
 - 2 Stock Brackets
 - 2 1/4" Thick Brackets with two holes for rear floor board mounts

