

Instructions for  
Linbar<sup>®</sup>, Multibar<sup>®</sup> and Unibar<sup>®</sup>  
Part # 602-1, 13602, 14602  
Fits Yamaha Road Star 1998-up.  
Will not fit the Meanstreak.



1. Remove allen bolts in left floorboard bracket and install supplied bracket between floorboard bracket and frame. Install bolts again but do not tighten yet. Do the same on right side floorboard.
2. Mount the lower mounting brackets of the Linbar / Multibar to the brackets you just installed.
3. Hold the top of the Linbar / Multibar up to the frame, there is some movement up and down. Find the center up and down and left and right, mark the spot, remove the Linbar / Multibar and drill hole (11/32").
4. Install the Linbar / Multibar and tighten all the bolts to manufacturer's specifications.
5. Hardware included:
  - 2 Hex bolts 3/8 x 16 x 1 1/4
  - 1 Hex bolt 3/8 x 16 x 2 1/2
  - 3 Nylon lock nut 3/8 x 16
  - 6 Sae flat washers 3/8
  - 2 Flat stock brackets 5 1/2

\*Bar width: 32 1/4"

