

Instructions for  
Linbar<sup>®</sup>, Multibar<sup>®</sup> and Unibar<sup>®</sup>  
Part # 606-1, 13606, 14606  
Fits Yamaha V Star 1300 2007-up



1. Uninstall the 2 bolts in front of the fuel tank on the left and right side of the frame.

Take the two bolts out that secure the rear brake master cylinder to the frame.

2. Remove left and right floorboard, install the 1/4" spacer between the frame and the floorboard bracket on the rear of the 2 mounting bolts.
3. Then install the lower mounts of the Linbar / Multibar between the frame and the floorboard bracket on the front bolt.
4. Then install the top of the highway bar with a spacer between the frame and the highway bar on the left and right side.

Install the rear brake master cylinder to the frame with supplied bolts and spacers. The spacers need to be mounted between the frame and the master cylinder.

5. Tighten all bolts to manufacturer's specifications.
6. Hardware included:

**\*Button Allen Head Bolts:**

- (1) 10 x 85 x 1.25
- (1) 10 x 50 x 1.25
- (2) 8 x 20 x 1.25

**\*Spacers:**

- (2) 1/4" O.D. 7/8"
- (2) 7/8" O.D. 7/8"
- (2) 1/4" I.D. 8mm O.D. 10mm

- (2) 10mm flat washers
- (2) 8mm flat washers