

Instructions for  
Linbar® and Multibar®  
Part # 607-1, 13607, 14607  
Fits Yamaha V Star / Tourer 950 2009-up



1. Loosen the front and rear bolts in the left and right floorboard brackets. Install the 6mm spacer on the rear bolts on the left and right side between the frame and the floorboard brackets. On the left side be sure to use the longer 10mm x 80mm bolts supplied in the hardware kit.
2. Install the lower brackets of the LINBAR/MULTIBAR to the front bolt for the floorboard brackets. The brackets on the highway bar will fit between the frame and the floorboard brackets.
3. Hold the top of the LINBAR/MULTIBAR against the top of the frame. Install the claw-like brackets between the frame and the highway bar so the brackets grab around the left and right down tube of the frame. Install the two 8mm bolts through the highway bar into the threaded brackets.
4. Tighten all bolts to manufacturer's specifications.

\*Hardware Included:

- 2 Spacers 1/4" x 7/8" o.d.
- 2 Hex head bolts 10mm x 80mm x1.25
- 10mm Flatwashers
- 2 Aluminum Claw Brackets
- 2 Hex Flange Head Bolts 8mm x 15mm x 1.25

