

Instructions for
Linbar® and Multibar®
Part #802-1, 13802 and 14802
Fits Suzuki Volusia 800cc 200-up



1. Remove rubber plugs in L & R down tubes.
2. Remove the front bolts from L & R floorboard mounts.
3. Install the L & R lower mounts of the Linbar using the 2 bolts you removed from the L & R floorboards.
4. Install the L & R upper mounts using the provided bolts and spacers, install the bolts where you removed the rubber plugs.
5. Tighten all bolts to manufacturer's specifications.
6. Hardware included:
 - (2) 10mm x 40mm 1.25 Tread
 - (2) 10mm flat washers
 - (2) Spacers 5/8" Long

*Bar width: 36"



Linbar patent number D361311
Multibar patent number D548142

View [other motorcycle frame & body](#) made by [Lindby Custom](#) on our [website](#).