

Instructions for  
Linbar<sup>®</sup>, Multibar<sup>®</sup> and Unibar<sup>®</sup>  
Part # 903-1, 13903, 14903  
Fits Kawasaki 900 cc/ Classic/ Custom



1. Remove the horn and mount it on the right side of the frame, just in front of the fuel tank. You need to take the 6mm bolt out and use the longer 6mm bolt and spacer included in the hardware kit.
2. Remove front bolts in left and right side floorboard/forward control mount. On the Custom, remove the rear bolt and install the 1/4 spacer between the frame and the forward controls.
3. Remove the Top bolt for the Radiator
4. Install the top mount of Linbar using the longer 6mm Bolt and washers provided in the hardware kit to the top radiator mount.
5. Install the two bolts you took out of the front floorboards/ forward controls. On the Custom, install the lower bracket of the highwaybar between the frame and the forward controls
6. Tighten all bolts to the manufacturer's specifications.

\*Hardware Included:

- 2 Hex Bolts 6mm x 40mm x 1.0
- 2 Flat washers 6mm
- 1 6mm fender washer
- 1 Spacer 1/4" chrome
- 2 x 1/4" spacer in Black



Linbar patent number D361311  
Multibar patent number D548142

View [other motorcycle frame & body](#) made by [Lindby Custom](#) on our website.