

Instructions for
Front Linbar[®], Multibar[®] and Unibar[®]
Part # 906-1, 13906, 14906
Fits Honda VTX 1800 Retro and N/S 2001-up
Does not fit the VTX 1800 Classic



1. Remove the 3 bolts that holds on the radiator to the frame and loosen the upper radiator hose clamp and rotate 180 degrees. Tighten again (make sure the engine is cold and that there is no pressure in the system).
2. Remove the 2 lower bolts in front of left and right floorboards. On the right side you may have to loosen the bolts on the floorboard to get the bolt out. On the left side, to get to the mounting point, you need to loosen the horn.
3. Install the top mount of the highway bar between the frame and the radiator and install the 6mm bolt. Do not tighten yet. Install the 2 lower bolts for the radiator.
4. Install the 2 lower bolts through the highway bar and into the frame (use the thick spacer on the left side and use the thin spacer on the right side). Tighten all bolts to the manufacturer's specifications.
5. Hardware included:
 - 1 Hex bolt 6mm x 35mm x 1.0
 - 1 Hex bolt 8mm x 45mm x 1.0
 - 1 Hex bolt 10mm x 120mm x 1.0

*Bar width: 35"



Linbar patent number D361311
Multibar patent number D548142

View [other motorcycle frame & body](#) made by [Lindby Custom](#) on our website.