Installation Instructions



	MWL-133
	FITMENT:
	Springer 97-Up, Heritage Springer 97-Up, &
	Springer Classic 05-Up
	MAX CAPACITY: 10 lbs
6	MATERIAL: 3/8" Solid steel
0	TECHNICAL SPECS: Pillion Seat Replacement
WELCOME: These instructions describe the procedure for properly installing the Motherwell Products Solo Luggage Rack.	USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and
ATTENTION INSTALLER (if other than owner): Please forward this instruction sheet to the	water. DO NOT use abrasive chemicals, cleaners. We recommend the use of non-abrasive automobile
purchaser of this product as it contains valuable	wax to polish our chrome products. This will best
information necessary to the end user.	maintain the appearance of the product and increase longevity.
CAUTION: Start screw carefully to avoid cross	
threading.	WARNING: Never carry more than 10 lbs on rack, and always secure cargo properly. Failure to do so can affect handling. Make sure neither cargo straps are loose and come in contact with moving parts, i.e., wheels, brakes, etc
TOOLS REQUIRED:	MOUNTING PROCEDURE:
#2 Phillips Screw Driver	1) Remove Pillion seat.
PARTS INCLUDED:	2) Install foam on back of the rack.
Luggage Rack	3) Slide rack into slots on front mounting knobs.
1 Phillips ¾" Pan Head Screw	4) Install the stock screw in to rear pick up point on
1 White Nylon Washer	the rack. (DO NOT TIGHTEN) 5) For the front mount, place the nylon washer on
1 Stainless Steel Washer	the rack with the stainless steel on top.
1 Foam Tab	6) From there insert the supplied Phillips screw
	loosely.
	7) Proceed to tighten both screws down.