

Installation Instructions



MWL-165/165B/166-09

FITMENT:

Sportster 04-Up, Dyna 06-Up, Springer & Heritage 00-Up, Fat Boy & Custom 00-Up

MAX CAPACITY: 10 lbs

MATERIAL: 5/8" Solid steel

TECHNICAL SPECS:

Fits the Harley-Davidson medium width sissy bar with spacing between uprights at 7.5".

WELCOME: These instructions describe the procedure for properly installing the Motherwell Products Solo Luggage Rack.

ATTENTION INSTALLER (if other than owner): Please forward this instruction sheet to the purchaser of this product as it contains valuable information necessary to the end user.

CAUTION: Start screw carefully to avoid cross threading.

USE AND CARE:

Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals, cleaners. We recommend the use of non-abrasive automobile wax to polish our products. This will best maintain the appearance of the product and increase longevity.

WARNING: Never carry more than 10 lbs on rack, and always secure cargo properly. Failure to do so can affect handling. Make sure neither cargo straps are loose and come in contact with moving parts, i.e., wheels, brakes, etc...

TOOLS REQUIRED:

"7/16 Socket or wrench

PARTS INCLUDED:

Luggage Rack
4 Hex Cap Screws
4 Black & Chrome Caps (MWL-166-09 Only)

MOUNTING PROCEDURE:

- 1) Remove backrest from the bike
- 2) Remove 4 existing bolts
- 3) Slide luggage rack from inside bottom backrest to align with existing bolt holes
- 4) Insert the 4 bolts provided and tighten evenly
- 5) Reinstall on bike