

Installation Instructions



<p>PICUTRE OF PRODUCT</p>	<p>MWL-167-06</p> <p><u>Fitment:</u> FITS 06-UP FOR SOFTAIL 2UP LUGGAGE RACKS</p> <p><u>MAX CAPACITY:</u> 10LBS</p> <p><u>MATERIAL:</u> 5/8" SOLID STEEL FOR PROPER FITMENT PLEASE MEASURE THE SPACING INBETWEEN THE SISSY BAR UPRIGHTS (9.5 inches)</p>
<p><u>Attention Installer (if other than owner):</u> Please forward this instruction sheet to the purchaser of this product. These instructions also contain valuable information necessary to the end user.</p>	<p><u>Mounting Procedure:</u></p> <ol style="list-style-type: none"> 1) Remove backrest from the bike 2) Remove 4 existing bolts 3) Slide luggage rack from inside bottom backrest to align with existing bolt holes 4) Insert the 4 bolts provided and tighten evenly 5) Then reinstall on bike.
<p><u>Welcome:</u> These instructions describe the procedure for properly installing the Motherwell Products Solo Luggage Rack.</p>	
<p><u>CAUTION:</u> Start screw carefully to avoid cross threading</p> <p><u>WARNING:</u> Never carry more than 10 LBS. on rack, and always secure cargo properly. Failure to do so can affect handling. Make sure neither cargo straps are loose and come in contact with moving parts, i.e. wheels, brakes, etc.</p>	<p><u>Use and Care:</u> Manufacturer's Tip: We recommend the use of non-abrasive automobile wax to polish our products. This will best maintain the appearance of the product and increase longevity.</p>
<p><u>Tools Required:</u> "7/16 SOCKET OR WRENCH</p> <p><u>Parts Included:</u> Luggage Rack 4 HEX BOLTS</p>	<p><u>Use and Care:</u> Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemical or cleaners, or high pressure washers.</p>