



INSTALLATION INSTRUCTIONS

BMW S1000XR 2015-

© by MRA-Klement GmbH – 09/2015 4025066154463

INSTALLATION INSTRUCTIONS

BMW S1000XR 2015-

Thank you for buying a MRA Windshield.

Read this manual carefully and check the parts list for completeness before you begin. We recommend that you have your screen fitted by an authorised workshop.

Number	Article	Article No..	Required tools
1	MRA screen	---	Torx TX 25 screwdriver 3 mm Allen key
1	Pair of holding plates	11089	
4	Round head screws, M5 x 16 mm	10554	
4	Round head screws, M5 x 20 mm	10673	
4	Plastic washers, 12 x 5 mm	10635	
4	Rubber nuts, M5	10629	
4	Spacers, 3 mm	10872	
4	O-rings, black, 4.5 x 1.5 mm	10992	
1	Edge protector strip with end sleeves	---	

How to mount the screen on your motorbike:

1. Stand your motorbike up on a level surface.
2. Dismantle the original screen.
3. Mount the brackets to your motorbike using the M5 x 16 mm Allen screws supplied.

⚠ The lugs on the brackets are different in length; mount each bracket with the longer lug in the downward position and the shorter lug in the upward position (P1).

4. Place the rubber nuts supplied into the drilled holes on the brackets.
5. Place the M5 x 20 mm round head screws with the plastic washers into the holes in your MRA screen. Place the spacers onto the screws from the inside. Tip: Place the spacers first, then the O-rings supplied onto the screws; this will help you mount the screen (P2).
6. Position our MRA screen on the brackets and tighten the screws.
7. Install the edge protector strip onto the screen as shown in P3. Place the end sleeves over the end of the edge protector strip and gently squeeze the sleeves with a pair of pliers to secure the edge protector strip.

After installation, check that all of the screws are tight; tighten them up if necessary. Repeat this at regular intervals. Clean the screen with water, neutral soap and a sponge. Do not use solvents, alcohol or spirits to clean the screen as they will damage it.



P 1



P 2



P 3

Functional Description

Variotouringscreen VT

Thank you for purchasing a Variotouringscreen. Please carefully read these instructions. You will get the most out of the adjustable spoiler if you thoroughly understand its features.

The spoiler serves to reduce air pressure on the rider's helmet and upper body without causing disturbing air turbulence. The spoiler has six different positions, enabling the rider to make adjustments to suit his needs. The higher the spoiler is set, the more air will flow between the spoiler and the windscreen. The airflow speed is reduced by means of the angle that opens in the direction of the rider, thereby providing at higher speeds the same relaxed atmosphere that a rider experiences at slow speeds.

- Raise the spoiler by manually pressing (Fig. 1) or pulling (Fig. 2) it upward, parallel to the windscreen.
- To make the spoiler flatter, push it downward in the direction of travel. (Fig. 3)

While adjusting the spoiler, make sure that it remains in the same position to the right and left.

Attention! Never attempt to adjust the spoiler while riding. The distraction will greatly increase the risk of accident!

VARIOTOURINGSCREEN FOR NAKED-BIKES:

- Recommended installation angle: 40-50°
- Recommended installation position: 10 - 20 mm gap to lamp.

Figure 1



Figure 2



Figure 3

