



## **INSTALLATION INSTRUCTIONS**

# **DUCATI**

## **Multistrada 1200 2015-**

## **Multistrada 950 2017-**

© by MRA-Klement GmbH – 11/2017 4025066153862

## INSTALLATION INSTRUCTIONS

### DUCATI Multistrada 950 17- / 1200 15-

*Thank you for buying a MRA Windshield.*

*Read this manual carefully and check the parts list for completeness before you begin. We recommend that you have your screen fitted by an authorised workshop.*

Number	Article	Article No..	Required tools
1	MRA screen	---	Allen key, 3 mm
2	Round head screws, M5 x 16 mm	10554	Allen key, 5 mm
1	Round head screw, M5 x 20 mm	10673	
3	Plastic washers, 12 x 5 mm	10635	
1	Neoprene sleeve, 10 mm	10688	
2	Neoprene washers, 16 x 4.5 x 4 mm	10634	

#### **How to mount the screen on your motorbike:**

1. Stand your motorbike up on a level surface.
2. Dismantle the original screen.
3. Insert the M5 x 16 mm round head screws with the plastic washers into the two **upper** holes on the MRA screen.
4. Place the 4 mm neoprene washers onto the upper screws from the inside (P1).
5. Insert the M5 x 20 mm round head screw through the **lower** hole on the MRA screen.
6. Place the 10 mm neoprene sleeve onto the lower screw form the inside (P1).
7. Position the MRA screen and tighten the screws.

**After installation, check that all of the screws are tight; tighten them up if necessary. Repeat this at regular intervals. Clean the screen with water, neutral soap and a sponge. Do not use solvents, alcohol or spirits to clean the screen as they will damage it.**



P 1



P 2