

ISTALLATION INSTRUCTIONS

KTM 1290 Super Duke GT 2016-

© by MRA-Klement GmbH - 07/2018 4025066163397

INSTALLATION INSTRUCTIONS KTM 1290 Super Duke GT 2016-

Thank you for buying a MRA Windshield.

Read this manual carefully and check the parts list for completeness before you begin. We recommend that you have your screen fitted by an authorised workshop.

Number	Article	Article No	Required tools
1	MRA windscreen		Torx T30
4	Brackets	10746	Allen key 3mm
4	Elastic nuts M5	10629	
8	Plastic washers 12x5x0.5mm	10635	
4	Lens head screws, M5x16mm	10554	
2	Allen screws with flange, M5 x 8 mm	11292	
2	Lens head screws, M5x30mm	10566	
2	Spacer sleeves, 20mm M6	11181	
1	Edge protection strip with clamping sleeves		

Fitting the screen to the motorcycle:

- 1. Place the motorcycle on a flat surface.
- 2. Dismantle the original screen.
- 3. Install the provided metal brackets [10746] on the lower screen fasteners (P1) using the 20mm spacers [11181] and the 30mm fillister head screws [10566].
- 4. Install the two remaining metal brackets [10746] on the upper screen fasteners (P2) using the 8mm fillister head screws [10554].
- 5. Apply the provided rubber nuts [10629] to the metal brackets (P1&P1).
- 6. Align the metal brackets as shown in figure 3, and tighten the screws.
- 7. Mount the MRA windscreen using the provided M5X16mm fillister head screws [10554] and the plastic washers [10635] onto the motorcycle and tighten the screws securely.
- 8. Apply the protective edge strip profile as shown in Figure 4. Cut off the rest if required.
- 9. Push the clamping sleeves over the ends of the protective edge strip and lightly compress them, using a pair of pliers to secure the protective edge strip profile.

After installation, check that all of the screws are tight; tighten them up if necessary. Repeat this at regular intervals. Clean the screen with water, neutral soap and a sponge. Do not use solvents, alcohol or spirits to clean the screen as they will damage it.



P 1





Р3

