



MOUNTING SUGGESTIONS:

Honda VT750 ACE 1998-2003 Solo and Passenger Seat

Hardware:	Solo seat: Stock rear bolt White nylon washer	Passenger seat: Stock rear bolt White nylon washer
Tools needed:	Metric wrenches	

Removal of stock seat:

1. Remove the bolt from the back of the passenger seat and set aside. This bolt is used to mount your new Mustang seat.
2. Slide the passenger seat forward and tilt upward to remove it from the motorcycle.



3. Remove the bolt from the back of the solo, and slide the solo back to remove from the motorcycle.

Installation of Mustang seat:

1. Engage the solo's front bracket with the frame receiver under the tank, position a nylon washer between the rear bracket and the fender, and install the stock bolt at the rear of the solo.
2. Slide the passenger seat's front bracket forward to engage the rear solo bolt.
3. Position a nylon washer between the rear bracket and the fender and secure with the stock rear bolt.

Enjoy the comfort and custom look of your new Mustang seat!



Refers to part numbers: 75000, 75001, 75003, 75004, 75005, 75006, 79150, 79151, 79153, 79154, 79155, 79156