



MOUNTING SUGGESTIONS:

Honda VT1100 Shadow-ACE-Spirit- Sabre - One-piece Seat

Hardware: Stock fender Allen screw
Nylon washer
Chrome mounting bracket
10/32 x 3/4" screw x 2

Tools needed: 10mm wrench
12mm socket wrench
Phillips screwdriver

These seats will install on the following motorcycles. If your motorcycle is not listed, please contact Mustang for fitment.

- VT1100 Shadow 1987-1997
- VT1100 ACE 1995-2001
- VT1100 Spirit 1997-2008
- VT1100 Sabre 2000-2008

Removal of Stock Seat:

1. Remove rear fender acorn nut with a 10mm wrench. This nut will be used to mount your Mustang seat.



2. *Shadow/Spirit:* Lift rear seat back and off the motorcycle, and remove the two bolts holding mounting bracket behind the solo seat.

3. *ACE/Sabre:* Remove the two mounting bolts on either side of the seat with a 12mm socket wrench.

4. Slide seat back and off the motorcycle.

Installation of Mustang Seat:

1. Mount the supplied bracket to the rear of the Mustang seat. For installation on 1997-2008 Spirit models, use the rear-most pair of holes (these may be under the vinyl). For all other models, use the forward-most pair of holes.



2. Engage the nose bracket into the receiver below the base of the fuel tank. Do **not** hook it under the fuel tank flange itself. This may require firmly pushing down on the nose of the seat.

3. Slide the seat **fully** forward to align the chrome rear bracket with the fender mount.

4. Place the nylon washer between the chrome bracket and the fender mount.



5. The bracket will be up to 1" above the rear mount. Push down on the rear of the seat, flexing the fiberglass baseplate, ensure all bumpers are directly contacting the fender, and secure with the stock acorn nut.

Enjoy the comfort and custom look of your new Mustang seat!



Handcrafted in  the USA

Looking for motorcycle seats & backrests? Visit our website.