



## MOUNTING SUGGESTIONS:

### Harley-Davidson® FX/FL Big Twin 1958-1984 One-piece Seat

<b>Hardware:</b>	Stock fender screw
<b>Tools needed:</b>	Phillips screwdriver

#### Removal of stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will

be used to attach your new Mustang seat.



2. Slide the seat up and back to disengage the front bracket and remove the seat.

#### Installation of Mustang seat:

1. Slide the front forks under the frame cross rail.

2. Align the rear tab with the fender hole.

3. Secure the rear bracket to the fender with the stock screw.

**Note:** The angles of the steel pan may need to be adjusted slightly to fit your specific bike.

**Enjoy the comfort and custom look of your new Mustang seat!**



These steps are guidelines to help you install your new Mustang product.

Refers to part numbers: 75057, 75060, 75302, 75442, 75511, 75619, 75630, 75734