



## MOUNTING SUGGESTIONS:

### Harley-Davidson® Sportster 1982-2003 One-piece Seat

<b>Hardware:</b>	Stock fender screw Black nylon washer (1996-2003 only)
<b>Tools needed:</b>	Phillips screwdriver

**Note: Certain Mustang seats will not install with specific fuel tanks. Please be sure your seat is correct for your tank size.**

#### Removal of stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.



2. If one-piece, slide the seat up and back to disengage the front bracket and remove the seat.

3. If two-piece, locate and remove fender bolt between the solo and passenger seat, then remove passenger seat, and then solo seat.

#### Installation of Mustang seat:

1. Insert nose tab into frame mount under tank. A firm downward chop to the nose will push it closer to the tank.

2. Align rear bracket with fender nut, position the nylon washer (if needed) between the bracket and the fender, and secure the bracket to the fender with the stock screw.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product..

Refers to part numbers: 75100, 75116, 75127, 75128, 75129, 75719, 75740, 75741,  
76397