



MOUNTING SUGGESTIONS:

Yamaha V-Star 650 1998-2017 One-piece Seat

Hardware:	Stock rear fender screw or nut Chrome rear mounting bracket 10/32 x 3/4" screw x 2 White nylon washer
Tools needed:	Phillips screwdriver Metric Allen wrenches and sockets

Removal of Stock Seat:

1. Remove the rear fender screw or nut.

2. Lift rear of passenger seat up and pull back to remove.



3. *Classic and Silverado:* Remove the two 6mm bolts from the fender bracket and remove. Remove 8mm bolt from back of the solo seat. Lift rear of solo up and pull back to remove. Re-install the stock bolts back into the fender holes.

4. *Custom:* Remove the two 6mm bolts from the fender bracket. Lift the solo up and pull back to remove. Re-install the stock bolts back into the fender holes.

Installation of Mustang Seat:

1. Install the provided chrome bracket to the seat pan with the provided screws.



- **Custom:** use the forward pair of mounting holes labeled "Custom"
- **Classic and Silverado:** use the rearward pair of mounting holes labeled "Classic" (as pictured above)

2. Slide the seat's nose bracket into the frame receiver at the base of the gas tank.

3. For models with a rear bolt, align the rear bracket with the fender hole and secure to the fender with the stock bolt.

4. For models with a fender stud and nut, place supplied nylon washer over fender stud, then lower seat bracket onto the stud. Put the stock chrome washer over the bracket, and secure with the stock nut.

Note: do *not* use the stock steel collar.

Enjoy the comfort and custom look of your new Mustang seat!



Handcrafted in  the USA

Looking for motorcycle seats & backrests? Visit our website.