



MOUNTING SUGGESTIONS:

Harley-Davidson® Softail 1984-1999 One-piece Seat

Hardware: Stock fender screw
Black nylon washer

Tools needed: Phillips screwdriver

These seats will install on the following motorcycles. If your motorcycle is not listed, please contact Mustang for fitment.

- FLST Heritage Softail 1986-1990
- FLSTC Heritage Softail Classic 1988-1999
- FLSTF Fat Boy 1990-1999
- FLSTN Nostalgia 1993-1996
- FXST Softail 1984-1999
- FXSTB Night Train 1999
- FXSTC Softail Classic 1986-1999
- FXSTS Springer 1989-1999
- FXSTSB Bad Boy 1995-1997

Removal of stock seat:

One-piece stock seat:

1. Remove the two mounting bolts from each side of the seat. These are not needed to mount the Mustang one-piece seat.
2. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.
3. Slide the seat up and back to disengage the front bracket and remove the seat.



Installation of Mustang seat:

1. Insert welded nose tab into frame mount under tank.
2. Align the rear bracket with fender nut, place the nylon washer between the bracket and fender, and secure the bracket to the fender with the stock screw.

Note: The angles of the steel pan may need to be adjusted slightly to fit your specific bike.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product.

Refers to part numbers: 75110, 75112, 75303, 75444, 75502, 75503, 75631, 75735, 76077, 76372, 76891