



MOUNTING SUGGESTIONS:

Harley-Davidson® FL Wrap-Around Backrest 1986-2013

Hardware:	1/4"-20 nuts x 3 1" zinc washer x 3 1" rubber washer x 6 Stick-on rubber pads x 3
------------------	--

Tools needed:	7/16" nut driver or wrench Phillips screwdriver
----------------------	--

Installation of Mustang Backrest:

Note: Mustang wrap-around backrest installs **ONLY** on King TourPaks and not on leather or chopped Paks.

1. Open TourPak, locate and remove the six hex nuts holding stock wrap-around unit in place and remove.



2. Note locations of all six holes in the lid. Mustang wrap-around uses the two outermost holes and the lower center hole only.



3. Remove all supplied hardware from the studs on the back of the Mustang wrap-around.

4. Place one rubber washer on each stud, align the studs with the holes in the TourPak, and push through.

Note: All three studs can be adjusted with a Phillips screwdriver for best fit. In the higher position, they will fit 1986-1999 TourPaks; in the lower position,

5. Place one rubber washer, one zinc washer and one hex nut on the studs inside of the lid. Tighten all three securely.

6. Cover the three unused holes in the TourPak with the stick-on rubber pads.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product.

Refers to part numbers: 75306, 75317, 75324, 75330, 75331, 75332, 79013