



## MOUNTING SUGGESTIONS:

### Harley-Davidson® FL Touring 1997-2018 Passenger Seat

<b>Hardware:</b>	Stock 1/4" -20 Rear fender Screw Black nylon washer (included if needed) Slotted mounting nuts/bolts x 2 (Mustang part 78028 for 1997-1998 or 78032 for 1999-up— <b>not included</b> )
<b>Tools needed:</b>	Phillips screwdriver

#### Mounting of Mustang seat:

1. CVO models: Remove any plastic trim from the fender so the Mustang passenger seat installs on the bare fender.
2. The two notches at the front of the baseplate engage the slotted bolts or nuts mounting the solo seat.
3. For seats without a built-in passenger backrest, place the black nylon washer between the fender and rear bracket, and secure with stock 1/4"-20 x 1/2" screw. Seats with a built-in passenger bracket have a stepped bracket and do not require a washer.

#### Passenger Backrest (if applicable):

1. The passenger backrest can be set forward or back with the 5/16"-24 x 3/4" adjustment screw.
2. The height of the passenger backrest can be set by tightening the rear knob to engage one of the notches on the post.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product.

Refers to part numbers: 75451, 75452, 75453, 75460, 75461, 75462, 75469, 75539, 75579, 76351, 76693, 76695, 76714, 76721, 76723, 79110, 79112, 79117, 79349, 79356, 79418, 79675, 79676, 79677, 79680, 79681, 79682, 79706, 79707, 79708, 79730, 79731, 79732